## Face Mount to Through-the-Post Mount

## Cable Runs through Two Corners

Deck 1 has only one end post at the corners. The posts next to the house butt right up to it so the back sides of those posts are not accessible.

Run #1 is still mounted *through the post*, so it will take a Series 212 or 232 kit. Runs #2 and #3 connect to the *face* of the corner post going back toward the house to keep the cables on the same plane. They also connect to the *face* of the posts next to the house as well.

## Use the 401 Series.

The tensioning device is an Adjust-a-Body® with Threaded Bolt, which threads into the metal post on one end. A Push-Lock® Threaded Bolt is threaded into the other end.

When taking cable railing through a corner, do not bend the cable past 45°. If turning 90°, a double corner post configuration is required as illustrated in Deck 2.



Series 401 Kits

Cable Length	1/8" cable	3/16" cable
	PART NO.	PART NO.
5′	40105	40105-6
10′	40110	40110-6
15′	40115	40115-6
20′	40120	40120-6
25′	40125	40125-6
30′	40130	40130-6
40′	40140	40140-6
50′	40150	40150-6





## Tools needed for 401 Series:

5/32 drill bit if 1/8" cable, 7/32 if 3/16" cable
Cutting tap drill bit I (for pilot hole) and 5/16-24 tap for threaded bolt installation
7/16 wrench for tensioning Adjust-a-Body®
3/8 wrench for installing Push-Lock® Threaded Bolt
Cable cutting tool

